



Protocol Dronium Two Rotor Blade Replacement

This guide is for removing the Protocol Dronium Two Rotor Blade

Written By: Edwin Brietz



INTRODUCTION

This guide is for replacing the Protocol Dronium Two. Included in your box should be four replacement blades. Do this repair in a clean and well lit place because the rotor blade screw is very small and easy to lose.



TOOLS:

- [Phillips #0 Screwdriver](#) (1)



PARTS:

- [Rotor Blade](#) (1)

Step 1 — Rotor Blade



- Turn off the drone by pushing the selector switch to the left.

Step 2



- Using the Phillips screwdriver included with the drone, carefully remove the 4.02 mm rotor blade screw.
- Once the screw is removed, remove the rotor blade by lifting the blade straight off of the drone

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-07-01 11:32:53 AM.